

MERCURY2 FAMILY

MER2-231-41U3M/C



- 2.3 Megapixels
- 1/1.2" global shutter CMOS sensor
- Ultra small, light and robust
- Compatible with GenICam[™] and USB3 Vision[®]
- USB3.0 interface
- 2 programmable GPIOs

The MERCURY2 USB3.0 series (MER2-U3) camera is DAHENG IMAGING's new generation area scan industrial digital camera, featuring outstanding performance, compact design and extremely low noise.

The MER2-231-41U3M/C camera is a monochrome/color USB3 Vision camera with the Sony IMX249 CMOS sensor. Thanks to the compact design (29mm × 29mm × 29mm), robust metal housings and locking screw connectors, the MERCURY2 cameras can secure the reliability of cameras deployed in harsh environments. The MER2-231-41U3M/C camera has opto-isolated I/Os. The GPIOs give MER2-U3 cameras maximum flexibility to adapt to specific needs.

The MERCURY2 family cameras are especially suitable for machine vision applications such as industrial inspection, medical, scientific research, education, security and so on.

Features

- USB3.0 interface with 12-bit, 10-bit or 8-bit Mono/Bayer output
- Programmable ROI, increased frame rate with partial scan
- · Gain, exposure and white balance programmable (white balance only for color models)
- Support auto gain, auto exposure and auto white balance (auto white balance only for color models)
- Three acquisition controls: Continuous acquisition/ Software trigger acquisition/ External trigger acquisition
- Flash sync for firing external lights at precisely the moment when exposure is performed
- Adjustable URB
- Software reset function
- Storable user sets
- Support Digital Shift
- Support Remove Parameter Limit to expand the range of exposure, gain, white balance, and so on
- Robust full metal housing and optional lockable devices
- Compatible with GenlCam[™] and USB3 Vision[®], support a variety of 3rd-party software such as HALCON, MERLIC and LabVIEW
- Optimized software package for 32/64bit Windows, and support Linux, Android, ARMv7 and ARMv8
- Multiple samples and easy-to-integrate SDKs for various programming tools
- Regulations: CE, RoHS, GenlCam, USB3 Vision



Performance Specifications

Model MER2-231-41U3M/C Interface USB3.0 Resolution 1920(H) × 1200(V)	
Resolution 1920(H) × 1200(V)	
Frame rate 41 fps @1920 x 1200	
Sensor 1/1.2", Sony IMX249 Global shutter CMOS	
Pixel size 5.86 μ m \times 5.86 μ m	
Pixel Bit Depth 8bit, 10bit, 12bit	
Spectrum Monochrome / Color	
Exposure time 20µs~1s	

Optical Specifications

Lens mount	C-Mount (standard), CS-Mount (optional)

Electrical Specifications

Power requirement	5 VDC via USB cable	
I/Os	1 input / 1 output , 2 GPIOs	
Data interface	Micro B with locked	
Power consumption <2.7W @5VDC		


Environmental Specifications

Operating temp.	0°C ~ +45°C
Storage temp.	-20°C ~ +70°C
Operating humidity	10% ~ 80%


Mechanical Specifications


Weight	65g
Dimensions	29(W)×29(H)×29(L)mm, w/o connectors

Technical Drawing



Spectral Response





China Daheng Group, Inc. Beijing Image Vision Technology Branch

12F Daheng Science & Technology Tower, No.3 Suzhou Street, Haidian District,

Beijing China, 100080 Tel: +86 10 82828878

E-mail: isales@daheng-imaging.com

For more information please visit: www.daheng-imaging.com/en